

Self-priming magnetic drive pumps

SMX-F

Chemically resistant self-priming magnetic drive pumps which can tolerate abnormal operation



Chemically resistant self-priming magnetic drive pumps which can tolerate abnormal operation



The SMX-F is a horizontal self-priming magnetic drive pump made from fluororesin.

Our original self-radiation structure enhances resistance to dry running, cavitation, and closed-discharge operation. In addition, the use of standard motors extends the range of application.



SMX-F543 SMX-F441 SMX-F221



Excellent corrosion resistance

The casings, impeller assembly and magnet capsule are made of fluororesin(CFRETFE). Other wet-end parts are made of highly corrosion resistant materials such as carbon, ceramic and the like. The pumps can handle almost type of chemicals including strong acid/alkali.




Expanded versatility

The SMX-F has a modular structure to handle liquids with high specific gravities. Use of standard motors extends the range of liquid application.




Easy maintenance

The pump wet end can be removed from the motor as a complete assembly without dismantling, thanks to an additional rear casing support. The pump wet end comprises the minimum number of parts for easy maintenance.





Our original self-radiation structure efficiently disperses bearing friction heat to protect the pump under abnormal operating conditions. In addition, our non-contact structure prevents contact between rear thrust face and bearing, to eliminate heat buildup during dry running.





Fast self-priming

The SMX-F requires no external self-priming chambers or valves. The gas-liquid separation design ensures fast self-priming. An exceptional self-priming duration of up to 4m in only 90 seconds is now possible.

Rear casing support

The pump wet end is easily removed from the motor by removal of 4 mounting bolts on the motor bracket. The rear casing support performs easy maintenance and draining of any residual liquid at other place.

Examples of application

Pumping up from underground tank


- Underground tank at chemical plant.
- Underground tank or pit of waste plant.


Pumping up and out from top of tank and tanker truck


- Transferring etching and plating chemical from chemical bath.
- Sucking up chemical from truck.
- Pumping up from top of tank.


Transferring chemical from tank to tank

- Transferring from main tank to daily tank.
- Refilling chemical from drum to tank.










Reliability and performance are enhanced by our unique design




Wet-end materials

Name of part		Model						
		CF	KK					
Front case								
Rear case								
Rear casing								
Volute spacer		CFRETFE						
Impeller								
Plate								
Magnet capsule								
O ring		FKM/EPDM						
Gasket								
Spindle		High purity alı	SiC					
Liner ring		riigii puiity ait	310					
Rear thrust	SMX-F22, 44							
	SMX-F54	High purity alu	SiC					
Rear thrust ring	Note2	-	High purity alumina ceramic	-				
Bearing		High density carbon	PTFE (With filler)	SiC				
Mouth ring		PTFE (With filler)						
Lock pin	Note1	CFRETFE						

Note1:54 type only

Note2 : Exclusive for SMX-F22RF, 44RF






- 1 Prime the pump with liquid.
- **2** On starting, the pump will suck both gas and liquid into its inlet. This mixture moves through front case A to the front casing, where it is agitated by the impeller. The mixture is discharged through pump chamber B to rear case C, where gas and liquid separation then occurs. Gas is bled from the discharge port **D** while some liquid is retained. Liquid in the rear case c is fed back through circulation hole **E** to the front casing, where it is again mixed with entrained gas by the impeller. This recirculation & bleeding process continues until gas from the suction side **F** is completely expelled.
- 3 Once all gas is expelled, normal centrifugal pump operation is resumed. Sufficient liquid remains in the casing for subsequent self-priming once the pump is stopped.

Specifications (50Hz)


Model	Connection	Impeller	Min. capacity	Standard specification	Max. capacity	Motor	Resisting pressure limit	Mass (Less motor)
	Suction×Discharge		(L/min)	(L/min-m)	(L/min)	(kW 2P)	(MPa)	(kg)
SMX-F220	25×25	V	10	50 - 9.6	85	0.37	0.28	14
SMX-F221		Т		100 - 12.5	115	0.75		
		V		80 - 7.5	125			
SMX-F222		Т		100 - 12.5	155	1.5		17.5
SMX-F441	40×40	Т	10	100 - 13.5	135	0.75	0.33	15.5
SMX-F442		Т		150 - 11.8	280	1.5		19
SMX-F542	50×40	V	20	100 - 19.8	155	1.5	0.40	28
SMX-F543		Т		250 - 16.0	440	2.2		
		V		200 - 16.0	410			
SMX-F545		Т		250 - 16.0	440	4.0		36
		V		200 - 16.0	410			

 $[\]bullet \text{Temperature range of handled liquid: 0 to 80°C (The self-priming height limit decreases at high temperatures.) } \\$


Pump identification



Dimensions (mm)



Performance curves



Capacity (L/min)

Precautions on the selection of pumps

- 1.The performance curves on this catalogue are based on the operation with 20°C clean water in flooded suction. Keep a margin (3% of the curves) when selecting the pump.
- 2. The magnetic pump cannot run continuously with a closed-discharge. Be sure to observe the minimum flow

The minimum flow rate SMX-F22 □: 10L/min SMX-F44□: 10L/min SMX-F54□: 20L/min

3. Select a pump model according to liquid specific gravity.

 $(margin) \stackrel{\cdot}{\leq} Motor\ output$

condition. Self-priming performance varies with liquid temperature, characteristics and piping conditions. Obtain a rough guide of the highest possible self-priming height at each liquid specific gravity by the following formula.

The highest possible self-priming height[m] = Self-priming height with clean[m] / Liquid specific gravity

Self-priming considerations

1.The diameter of the piping on the suction side should be the same as that of the pumps inlet port,

SMX-F22 □: 25mm SMX-F44 □: 40mm SMX-F54□: 50mm


and the length of the piping should be limited to less than 4.7m. A larger pipe diameter or longer piping could adversely affect the self-priming performance, or could even hinder the self-priming pro-

- 2.In cases where the liquid level fluctuates, take the height from the lowest liquid level as the maximum self-priming height.
- Always keep 10% allowance to motor output.

 Pump shaft power Sp x Specific gravity x 1.1 3.Always perform priming before first operation, and start the pump only after the pump chamber has been filled with the handled liquid.
- 4.The self-priming performance (4m in 90 seconds) is based 4.To prevent early deterioration, avoid frequent start/stop of the on the operation with 20°C clean water on the right piping pump.
 - 5.If a foot valve is installed on the suction pipe, pipe resistance may increase so that the pump cannot suck liquid enough.

6. When installing a check valve, install an air vent line to release the air.

If piping weight loads the pump, plastic parts are deformed. Be sure to install a pipe support.



Optional accessories

Iwaki pump protector DRN series

Detects unusual pump operating conditions including dry-running and overload

The DRN model protects equipment (including pumps) from damage! Minimizes production downtime.

Identifies possible causes of alarms so they can be investigated and addressed.



Multiple Input Two analog, one digital, one temperature input and one current input Equipped with EASY setup mode to remember the operation status Easy operation

and set the lower/upper limit values, as well as AUTO setup mode Bar graph Visible indication of current operating status Logging capability Data log feature for preventative maintenance scheduling

Communication RS485 external communication capability Specifications

Model	DRN-01	DRN-02		
Amperometric range	0.5-30.00A	5.0-200.0A		
Unit's source voltage	AC100-240V 50Hz 10VA			
Operating temperature	0–40°C			
Operating humidity	35-85%RH			

IWAKI CO., LTD. 6-6 Kanda-Sudacho 2-chome Chiyoda-ku Tokyo 101-8558 Japan TEL: (81)3 3254 2935 FAX: 3 3252 8892

IWAKI has global net work.
Please find your distributor location at

TEL: (49)2154 9254 0 European Headquarter **IWAKI Europe GmbH** FAX: (49)2154 9254 48 IWAKI America Inc. TEL: (1)508 429 1440 Germany **IWAKI Europe GmbH** TEL: (49)2154 9254 50 FAX: (49)2154 9254 55 Argentina (Argentina Branch) IWAKI America Inc. TEL: (54)911 6477 4116 TEL: (31)74 2420011 FAX: (49)2154 9254 48 IWAKI Do Brazil Comercio De Bombas Hidraulicas LTDA. TEL: (55)19 3244 5900 IWAKI Europe GmbH Brazil FAX: (55)19 3244 5900 Italy (Italy Branch) IWAKI Europe GmbH TEL: (39)0445 561219 FAX: (39)0445 569088 China (Shanghai) IWAKI Pumps (Shanghai) Co., Ltd. TEL: (86)21 6272 7502 FAX: (86)21 6272 6929 IWAKI Pumps Co., Ltd. TEL: (852)2607 1168 TEL: (34)934 741 638 FAX: (34)934 741 638 China (Hong Kong) FAX: (852)2607 1000 Spain (Spain Branch) **IWAKI Europe GmbH** GFTZ IWAKI Engineering & Trading Co., Ltd. TEL: (86)20 84350603 IWAKI Singapore Pte Ltd. TEL: (65)6316 2028 Poland (East Europe Branch) IWAKI Europe GmbH TEL: (48)12 347 0755 FAX: (48)12 347 0900 China (Guangzhou) FAX: (86)20 84359181 IWAKI Nordic A/S TEL: (45)48 242345 FAX: (65)6316 3221 Denmark Singapore IWAKI Singapore Pte Ltd. IWAKIm SDN. BHD. IWAKI Suomi Oy TEL: (358)10 201 0490 Indonesia (In TEL: (62)21 6906606 FAX: (62) 21 6906612 Finland IWAKI Norge AS TEL: (47)23 38 49 00 TEL: (60)3 7803 8807 FAX: (60)3 7803 4800 Norway Malavsia IWAKI Sverige AB IWAKI Belgium N.V. IWAKI Korea Co., Ltd. IWAKI Pumps Taiwan Co., Ltd. FAX: (82)2 6238 4801 FAX: (886)2 8227 6818 Sweden TEL: (46)8 511 72900 Korea TEL: (82)2 6238 4800 TEL: (32)13 670200 FAX: (32)13 672030 TEL: (886)2 8227 6900 Belgium Taiwan IWAKI France S.A. TEL: (33)1 69 63 33 70 FAX: (33)1 64 49 92 73 Thailand IWAKI (Thailand) Co.,Ltd. TEL: (66)2 322 2471 FAX: (66)2 322 2477 IWAKI Pumps Australia Pty Ltd. TEL: (61)2 9899 2411 FAX: (61)2 9899 2421 ()Country codes Australia

Caution for safety use:

Before use of pump, read instruction manual carefully to use the product correctly. Actual pumps may differ from the photos. Specifications and dim



Legal attention related to export.

Our products and/or parts of products fall in the category of goods contained in control list of international regime for export control. Please be reminded that export license could be required when products are exported due to export control regulations of countries.

The posting and copying from this catalogue without permission is not accepted firmly.